

# External Image Capture

and Video Recorder Device, Full HD



Quality of Inspection

Plug-&-play Full HD Image Capture and Video Recorder device with remote control.



Compatible with Full HD (1080p) output signals of Inspectis F30 and F30s Digital Microscopes. Captures live video and still pictures up to 1080P resolution (1920x1080 pixels) on SD-card or USB flash memory without need of host computer.

Live Video Loop at 1080p 60 fps. Microphone Input for Audio Recording and Speaker Output are also available. Still image and video capture via an easy-to use Remote Controller.

## Specification:

Storage Media	USB flash memory stick and SD-Card.
Video Input / Output Interface	HDMI
Video Recording Codec	Hardware H.264 encoder
Input Resolution	1920x1080 (50p, 60p)
Output Resolution, Video Capture	1920x1080 (30p)
Output Resolution, Video Loop	Same as output Resolution
Video/Audio Recording Format	MP4 / AAC Stereo
Size / Weight	141(L) × 75(W) × 23(H) mm, 120 g

## Ordering Number/Name

**HD-140-F-EU** Inspectis Full HD External Image Capture and Video Recorder for F microscopes (EU cable)

**HD-140-F-US** Inspectis Full HD External Image Capture and Video Recorder for F microscopes (US cable)

**HD-140-F-UK** Inspectis Full HD External Image Capture and Video Recorder for F microscopes ( cable)

Reseller:



V1, 2019

[www.inspect-is.com](http://www.inspect-is.com)