

External Image Capture

and Video Recorder Device, Full HD



Quality of Inspection

High-quality, plug-&-play Full HD Image Capture and Video Recorder device.



Compatible with HD (720p), Full HD (1080p) and 4K (2160p) output signals of Inspectis Digital Microscopes. Captures live video and still pictures up to 1080P resolution (1920x1080 pixels) via USB flash drive interface without need of host computer.

Live Video Loop at 1080p 60 fps, Playback function, Live Streaming to PC, Microphone Input for Audio Recording and Speaker Output are also available. All functions are controlled via an easy-to use Remote Controller.

Assembled in industrial grade aluminum housing with stainless-steel bottom plate.

Specification:

Storage Media	USB flash drive, USB portable hard disk, 2T max capacity
Video Input / Output Interface	HDMI
Video Recording Codec	Hardware H.264 encoder
Input Resolution	3840x2160 (30p), 1920x1080 (50p, 60p), 1280x720 (50p, 60p)
Output Resolution, Capture	1920x1080 (30p), 1280x720 (60p)
Output Resolution, Video Loop	Same as output Resolution, Capture
Video/Audio Recording Format	MP4 / AAC Stereo
Size / Weight	140(L) × 70(W) × 18(H) mm, 260 g

Ordering Number/Name

HD-140 Full HD External Image Capture and Video Recorder

Reseller:



MicroscopeWorld

V4, 2018

www.inspect-is.com